

BIZHUB 363

Meter Read Retrieval

1. Press **{Utility/Counter}**
2. Select **{Meter Count}**
3. Select the **{Check Details}**
4. Select the **{Print List}**
5. Press **{Start}**